



FLEXITEEK TEMPLATE MAKING...VERY EASY!

To template, you may use builder's paper (craft, packaging or shipping) normally available in a 30" wide roll at any hardware store like Lowe's or Home Depot. Cut pieces off the roll big enough to cover the area you wish to template. If requiring more than one piece of paper, tape sheets together with strong tape (do not use painters tape).

Boats have a non-skid texture added or molded into the deck surface. Flexiteek normally covers this non-skid area. There may be exceptions to this method such as step areas where you might want to cover the entire step area rather than just the non-skid.

Take a crayon and strip the paper from it. Locate on the deck where the non-skid begins and by using the edge of the crayon, rub gently on the paper revealing a "rubbing" of the perimeter of the non-skid. By using the correct pressure it will be easy to see on your template where the non-skid starts and ends. Continue to create your template in this way until you have a "rubbing" of the entire deck area. Do not forget to indicate any hardware such as cleats, stanchions, hatches and pedestals.

Once you have completed all of your templates, make "reference lines" from one template to the next so that the caulk lines will be aligned from piece to piece.

Write clearly on each template "This side up" and "Fore" and "Aft". Any special instructions can also be written on the template or any other note that may help us understand what the finished panel should look like.

You can now remove each paper template and cut it to size with scissors using the "rubbing" as a guide. Fit the trimmed template back on to the deck and make sure that the template fits the deck area exactly the way you want the finished deck to fit. The template is now complete and should be mailed to:

SeaJay Marine Group
1623 Mill Street
Algonac, MI 48001

Please call us at 313-402-3685 if you have any questions about the template process.